

## AIRCRAFT CHECKLIST - PIPER ARROW IV 2919U

### CABIN

Airworthiness certificate .....CHECK  
 Registration.....CHECK  
 Operators handbook.....CHECK  
 Weight and balance .....CHECK  
 Maintenance items... CHECK CURRENT  
 Control wheel .... RELEASE RESTRAINTS  
 Master switch ..... ON  
 Fuel quantity..... CHECK QUANTITY  
 Stall warning .....CHECK  
 Anti-collision lights..... ON\*  
 Nav light..... ON\*  
 Taxi/Lnd light ..... ON\*  
 Pitot heat ..... ON\*

\* check functioning as needed

Master..... OFF  
 Gear lever ..... DOWN  
 Flaps ..... LOWER  
 Pitot and static system..... DRAIN  
 Windshield ..... CHECK CLEAN

### RIGHT WING Trailing Edge

Baggage door ..... CLOSE & SECURE  
 Flaps & hinges.....CHECK  
 Aileron & hinges .....CHECK

### RIGHT WING

Wing tip and light.....CHECK  
 Wing tie down..... DISCONNECT  
 Main tire ..... CHECK (30psi)  
 Main gear strut ..... 2.5" ±.25"  
 Fuel sump..... DRAIN SAMPLE  
 Fuel tank ..... CHECK quantity  
 Fuel cap..... SECURE  
 Fuel tank vent ..... CLEAR

### NOSE

Engine oil ..... Min 4/Fill to 7/Max 8  
 Fuel strainer..... DRAIN  
 Prop & spinner..... CHECK for damage  
 Nose wheel strut..... 2.75" ±.25  
 Nose wheel tire..... CHECK (27psi)

### LEFT WING

Wing tip and light.....CHECK

Wing tie down..... DISCONNECT

Main tire ..... CHECK (30psi)

Main gear strut ..... 2.5" ±.25"

Fuel sump..... DRAIN SAMPLE

Fuel tank ..... CHECK quantity

Fuel cap..... SECURE

Fuel tank vent ..... CLEAR

Stall warning .....CHECK

Pitot/static head ..... REMOVE

### LEFT WING Trailing Edge

Flaps & hinges.....CHECK  
 Aileron & hinges .....CHECK

### FUSELAGE

Antennas.....CHECK  
 Stabilator & trim tab .....CHECK  
 Tie down ..... REMOVE

### BEFORE STARTING ENGINE

Preflight inspection .....COMPLETE  
 Passenger brief .....COMPLETE  
 Hobbs and tach times .....RECORDED  
 Seats.....AJUST & LOCK  
 Seat belts .....AJUST & LOCK  
 Master avionics switch ..... OFF  
 Brakes .....TEST  
 Parking brake .....SET  
 Circuit breakers ..... CHECK IN  
 Propeller ..... FULL FORWARD  
 Alternate air ..... OFF

### STARTING ENGINE

Anti-collision switch ..... ON  
 Throttle ..... OPEN 1/2 inch  
 Master switch ..... ON  
 Fuel selector valve ..... LOWEST TANK  
 Electric fuel pump ..... ON  
 Mixture ..... PRIME then OFF  
 Propeller area ..... CLEAR  
 Ignition switch ..... START  
 Mixture ..... FULL RICH  
 Electric fuel pump ..... OFF  
 Copyright © Aerotech Aviation Ver 9  
 updated 01/03/2020

**AFTER ENGINE START**

Throttle ..... ADJUST 800-1000 RPM  
Oil pressure ..... CHECK  
Mixture ..... LEAN for taxi (1")  
Fuel monitor ..... SET

**BEFORE TAXI**

Annunciator panel ..... CHECK  
Gear indicator lights ..... ON  
Master avionics switch ..... ON  
Crew communication ..... CHECK  
ATIS ..... OBTAIN  
Clearance ..... OBTAIN  
Transponder ..... SET SQUACK CODE  
Transponder ..... SET ALT  
NAV/ADS-B ..... ON  
Flaps ..... UP  
Parking brake ..... RELEASE  
Rolling brake test ..... TEST

**BEFORE TAKEOFF (run up)**

Parking brake ..... SET  
Cabin doors ..... CLOSED and LATCHED  
Flight controls ..... FREE and CORRECT  
Flight instruments ..... SET  
Fuel selector valve ..... FULLEST TANK  
Elevator & rudder trim ..... SET  
Flaps ..... SET  
Throttle ..... 2000 RPM  
Mixture ..... SET FOR ALTITUDE  
Prop ..... CYCLE 3X  
Magnets ..... 175 drop either  
50 differential  
Oil pressure ..... CHECK  
Oil temp ..... CHECK  
Ammeter ..... CHECK  
Fuel pressure ..... CHECK  
Vacuum ..... 4.8 to 5.1  
Throttle ..... 800 to 1000 RPM  
Friction lock ..... SET  
Radios ..... SET and CHECK  
Lights ..... AS REQUIRED  
Takeoff brief ..... COMPLETE  
Time ..... CHECK  
Brakes ..... RELEASE  
Fuel pump ..... ON

**NORMAL TAKEOFF**

Wing flaps ..... SET  
Throttle ..... FULL OPEN  
Elevator control ..... Rotate at 65 KIAS  
Climb speed ..... 75 KIAS

**SHORT FIELD TAKEOFF**

Wing flaps ..... 25°  
Runway ..... USE ALL  
Brakes ..... APPLY  
Throttle ..... FULL OPEN  
Engine instruments ..... CHECK  
Flight controls ..... NEUTRAL  
Brakes ..... RELEASE  
Elevator ..... ROTATE at 55 KIAS  
Climb speed ..... 60 KIAS  
Gear ..... UP  
Climb speed ..... 75 KIAS  
-After clearing obstacle  
Flaps ..... UP incrementally  
Climb speed ..... 85 KIAS

**SOFT FIELD TAKEOFF**

Wing flaps ..... 25°  
Elevator control ..... FULL UP  
Taxi ..... CONTINUOUS  
Throttle ..... FULL OPEN  
Stay in ground effect until 60 KIAS  
Gear ..... UP  
Climb speed ..... 75 KIAS (Vx)  
Flaps ..... 0°  
Climb Speed ..... 85 KIAS

**AFTER TAKEOFF**

Flaps ..... UP  
Gear ..... UP  
Climb speed ..... 87 KIAS  
Prop ..... SET  
Engine instruments ..... CHECK  
Fuel pump ..... OFF  
Lights ..... AS REQUIRED

**ENROUTE CLIMB**

Airspeed ..... 100 KIAS  
Propeller ..... FULL FORWARD  
Throttle ..... FULL OPEN  
Mixture ..... LEAN for altitude

## **CRUISE**

Manifold press ..... SET  
 RPM ..... SET  
 Elevator Trim ..... ADJUST  
 Rudder Trim ..... ADJUST  
 Mixture ..... LEAN for altitude  
     EGT ..... set 75° less/rich of peak  
 Switch tanks at 30 min and every hour thereafter.

## **DESCENT**

Mixture ..... FULL RICH  
 Alt Air ..... CLOSED

## **IN RANGE (when in radio range)**

ATIS ..... GET WEATHER INFO

Altimeter ..... SET

Align DG with Compass ..... COMPLETE

Avionics ..... SET

Approach Brief ..... COMPLETE

## **BEFORE LANDING**

Gas (fuel selector) ..... FULLEST TANK

Under Carriage (gear) ..... DOWN

Mixture ..... RICH

Props ..... SET FOR LANDING

Seat Belts ..... ON

Switches ..... LIGHTS AS REQUIRED  
     AUX FUEL PUMP ON

## **NORMAL LANDING**

Approach speed ..... 80 KIAS

Wing Flaps ..... AS REQUIRED

Final Airspeed ..... 70 KIAS

Throttle ..... REDUCE to idle

Touchdown ..... MAIN WHEELS 1ST

Brakes ..... MIN REQUIRED

## **SHORT FIELD LANDING**

Gear ..... DOWN

Airspeed ..... 70 KIAS (-0/+10)

Flaps ..... 40°

Throttle ..... IDLE when appropriate

Touchdown ..... MAIN WHEELS FIRST

Brakes ..... APPLY HEAVILY

Flaps ..... 0°

Elevator ..... FULL BACK

## **SOFT FIELD LANDING**

Airspeed ..... 80-70 KIAS  
 Wing Flaps ..... 40°  
 Final Airspeed ..... 65 KIAS  
 Throttle ..... ABOVE IDLE  
 Touchdown ..... SOFTLY  
 Nose Wheel ..... KEEP UP  
 Elevator ..... FULL BACK  
 Brakes ..... MIN REQUIRED

## **REJECTED LANDING (go around)**

Throttle ..... FULL OPEN  
 Airspeed ..... 70 KIAS  
 Gear ..... UP  
 Airspeed ..... 77 KIAS  
 Wing Flaps ..... RETRACT incrementally

## **AFTER LANDING**

Flaps ..... UP  
 Mixture ..... LEAN for taxi (1")  
 Transponder ..... AS REQUIRED  
 Aux Fuel Pump ..... OFF  
 Lights ..... AS REQUIRED

## **ENGINE SHUTDOWN**

Parking Brake ..... AS REQUIRED  
 ELT ..... VERIFY NOT ACTIVE (121.5)  
 Master Avionics ..... OFF  
 Switches ..... OFF  
 Mixture ..... IDLE CUT OFF

Master Switch ..... OFF

Ignition Switch ..... OFF

## **SECURE AIRCRAFT**

Yoke ..... SECURE WITH SET BELT  
 Wheel Chocks ..... PLACE  
 Tie Downs ..... ATTACH  
 Doors ..... LOCK

## **EMERGENCY PROCEDURES**

### **ENGINE FAILURE DURING TAKEOFF**

Throttle ..... IDLE  
Brakes ..... APPLY  
Wing flaps ..... RETRACT  
Mixture ..... IDLE CUT-OFF  
Ignition switch ..... OFF  
Master switch ..... OFF

### **ENGINE FAILURE**

#### **IMMEDIATELY AFTER TAKEOFF**

Mixture ..... FULL RICH  
Fuel selector valve ..... SWITCH  
Fuel pump ..... CHECK ON  
If no power, go to forced landing

### **ENGINE FAILURE DURING FLIGHT**

Mixture ..... RICH  
Prop ..... FULL FORWARD  
Fuel pump ..... ON  
Alternate Air ..... ON  
Ignition switch ..... BOTH  
Fuel selector ..... SWITCH TANKS

### **FORCED LANDING**

Airspeed ..... 79 KIAS  
Mixture ..... IDLE CUT-OFF  
Fuel pump ..... OFF  
Fuel selector valve ..... OFF  
\* If time permits: Emergency call,  
squawk 7700, brief passengers,  
stow loose articles

Gear ..... AS REQUIRED  
Master switch ..... OFF  
Wing flaps ..... 40°  
Touchdown .... SLIGHTLY TAIL LOW

### **ENGINE FIRE DURING START**

Cranking ..... CONTINUE  
If engine starts:  
Power..... 1700 RPM for a few minutes  
Engine ..... SHUTDOWN  
If engine fails to start:  
Cranking ..... CONTINUE

Fire extinguisher ..... OBTAIN

Mixture ..... IDLE CUTOFF

Throttle ..... OPEN

Fuel pump ..... OFF

Fuel selector valve ..... OFF

Fire ..... EXTINGUISH

### **ENGINE FIRE IN FLIGHT**

Mixture ..... IDLE CUT-OFF  
Fuel selector valve ..... OFF  
Fuel pump ..... OFF  
Master switch ..... OFF  
Cabin heat & air ..... OFF  
Emergency descent ..... INITIATE

### **CABIN FIRE IN FLIGHT**

Master switch ..... OFF  
Vents ..... OPEN  
Heat ..... CLOSED  
Fire extinguisher ..... EXTINGUISH  
Emergency descent ..... INITIATE

### **EMERGENCY DESCENT**

Airspeed ..... 108 KIAS  
Gear ..... DOWN  
Wing flaps ..... 40°  
Rudder ..... FULL SLIP

### **EMERGENCY GEAR EXTENSION**

Master switch ..... ON  
Circuit breakers ..... CHECK  
Panel lights ..... OFF (in daytime)  
Gear indicator bulb ..... CHECK  
Airspeed ..... below 87 KIAS  
Gear lever ..... DOWN  
Emer gear lever ..... PUSH DOWN  
If gear still is not locked down:  
-Yaw aircraft rapidly back and forth  
-Recycle gear lever